




(813) 928-1449


www.FFPCustoms.com

1979-1993 Mustang Sportsman's Pedal Assembly Main Structure & Brake Pedal Instructions



FFP Customs prides itself on not only manufacturing quality parts, but also offering real world, race car solutions. Our Patented Pedal Assembly is another product aimed at improving your experience behind the wheel of your race car. These instructions are designed to make installing your new FFP Customs Pedal Assembly that much easier, so follow along as we guide you through the installation process.

Copyright © 2021 Frazier's Fabrication & Performance. All Rights Reserved.



When you open your FFP Customs pedal assembly box, this is how it will be arranged. Depending on the pedal assembly you have ordered, each individual pedal will be pre-assembled, as will the pedal assembly's main structure, off which everything is built. So, along with the subassemblies, and Wilwood master cylinder box, we also have hardware bags that go with the appropriate subassembly. With the main structure and brake pedal assembly we include hardware bags for the pedal pad, cowl panel mount, reservoir mount, and brake master cylinder mount.


Pedal Assembly Contents

Billet Components of the Kit

- Pedal Assembly main structure, preassembled.
- Brake Pedal pre-assembled.
- Throttle Pedal, if applicable. Refer to those instructions for the full list of associated hardware
- Clutch Pedal, if applicable, pre-assembled. Refer to those instructions for the full list of associated hardware
- Pedal Pads for each included pedal.
- Wilwood Master Cylinder

Main Structure Hardware Bags and Contents


- Cowl Panel Mount 79-93
 - 5/16-18 x 1" Grade 8 Bolt x 2
 - 2 Grade 8 Washers
- Brake Master Cylinder Mount
 - 3/8-24 x 2" Studs x 2
 - 3/8 Grade 8 Washer x 2
 - 3/8 Spring Washer x 2
 - 3/8" Heim Joint
 - 3/8 Shoulder Bolt
 - 3/8-24 Finish Nut x 2
 - 5/16-18 Lock Nut
 - 1/4-20 x 1" Locking Thread Bolt x 4
 - 1/4" washer x 4
 - 1/4" spring washer x 4
- Pedal Pad
 - 1/4-28 x 1-1/2" x qty 2
 - 1/4" washer x 4
 - 1/4-28 Lock Nut x 2



The Pedal Assembly's main structure installs using the outside firewall mount and the inside firewall mount. The main structure is the building block of the pedal assembly. Everything is built off the main structure. The main structure bolts to the firewall and the cowl area under the dash. The cowl mount is part of the main structure and that part bolts the main structure and cowl area. Then the brake master cylinder and brake pedal are attached to the main structure in the center.


The main structure is the key to our pedal assembly. Once you have the main structure installed, the rest of the installation is a matter of adding the brake pedal and master cylinder, the throttle pedal, and if applicable, the clutch pedal. When you receive it, the main structure's inside and outside firewall mount is already attached. Detach the outside firewall mount and feed its studs through the factory power booster holes in the firewall. Then, on the inside, attach the main structure to the studs, and bolt the two together. Next, take the supplied two 5/16-18 bolts with washers, and fasten the front cowl panel to the factory mounting holes on the cowl.

The master cylinder bolts to the brake pedal and the master cylinder mount, and then the subassembly is fitted to the center of the main structure. Once a comfortable seating position has been attained, mark the main structure where you want to mount the brake pedal and master cylinder. The brake pedal and master cylinder will need to be removed, and bench bled prior to final assembly. It should be noted that the bolts used to mount the brake sub assembly to the main structure have a locking thread, so you will feel some tension once you get the bolt started. We've included spring lock washers for these bolts also as a secondary lock.



Not only is the brake pedal assembly adjustable fore and aft, but you can also adjust pedal height, thanks to extra holes at the bottom of the brake pedal. Attach the included Wilwood master cylinder to the brake pedal subassembly and it is ready to be attached to the main structure. We include a threaded Heim joint to connect the master cylinder to the brake pedal at the top. The Heim joint shoulder bolt and nut need to be arranged in this fashion to provide clearance for full brake pedal travel. This is looking down at it from overhead. Make sure not to preload the master cylinder or you could cause brake drag.

With the main structure, brake pedal and master cylinder installed, do not tighten everything until you have adjusted it to your liking and bled the master cylinder. With the master cylinder bled and everything firmly attached, the brake pedal portion of the installation is done.



- 1/2" Banjo bolt
- 9/16" Inner diameter sealing washer
- -3AN Banjo
- 1/2" Inner diameter sealing washer

This is the correct orientation for the pressure output fittings that will be screwed into the brake master cylinder.

If you have made it this far, you have completed the installation of the FFP Customs Patented Pedal Assembly's main structure and brake pedal subassembly. If you have also ordered a throttle pedal and/or clutch pedal subassembly as part of your FFP Customs pedal assembly, we have included separate instruction sheets to ease the installation of those subassemblies.

If you have any installation concerns or roadblocks, please call us. We would rather you call us for clarification instead of being frustrated with the installation.

Proudly Made in the USA.

FFP Customs

(813) 928-1449

Patented Pedal Assembly 1979-1993 Mustang Throttle Pedal Instructions



If you are reading this, you have already installed the FFP Customs pedal assembly's main structure and brake pedal subassembly. With that, you can move on to the throttle pedal subassembly. As we have mentioned, everything is built off the pedal assembly's main structure. As such, the throttle pedal uses the main structure as its attaching point.



The throttle pedal is sectioned off by itself in the box when you receive the pedal assembly. It uses a throttle pedal stop and hanger that attach it to the main structure. This is the throttle pedal stop and hanger (Right). It attaches to the pedal, which attaches the pedal to the main structure.




Additional hardware for the throttle pedal is for the pedal pad installation and for the throttle cable firewall bracket.

Make sure all components above are in your kit before moving on. This includes

- Billet Throttle Pedal and throttle pedal pad
- Throttle Pedal Hanger + Throttle pedal Stop with mount hardware installed as pictured
- Pedal Pad Hardware which includes 2 ¼-28 x 1-1/2" Long Bolts, 4 washers, and 2 Locknuts
- Throttle Cable Firewall Bracket with 2 sheet metal mounting screws

At the top of the throttle pedal is where you attach the throttle cable. The pedal has 3 pivot holes to adjust it up or down. Of the three pivot holes in the center of the pedal, we use the middle hole to best line up to our throttle cable firewall bracket. At the bottom of the throttle pedal there are three adjustment holes for the pedal pad. The adjustment holes are designed to help you arrive at the throttle pedal's sweet spot.



The throttle pedal is mounted to the main structure through the throttle stop and hanger mounting arm. Either way you choose to mount the throttle pedal, whichever is easier would be what we recommend. The orientation of the throttle pedal assembly hardware with the optional wide open throttle switch is on the right. You have the stud, which is threaded into the hanger, a large oil-impregnated bronze bushing, the pedal itself, small oil-impregnated bronze bushing, flat washer, and lock nut. Do not overtighten the throttle pedal nut because that will keep it from being able to move. Finding the optimum torque setting is up to your individual combination because that setting will vary depending on your return spring setup.

When it comes to the throttle pedal, we do have an optional throttle switch that can be attached to the throttle pedal stop. You can set this up as a wide-open throttle switch to control a nitrous system, or any other system that works off wide open throttle. The switch provision is in the mount, regardless of if you order the switch at the time of purchase or not. Therefore, if at the time of purchase, you do not need it, but later you add nitrous or another system needing to see WOT, the switch can still be added to the throttle pedal mount.

The installation of the throttle pedal is straightforward. The most important aspect of the throttle pedal assembly is the tightening of the pedal nut to the mount. You will have to find the happy medium between too tight and too loose to arrive at the proper torque setting. Aside from that, the throttle pedal is a simple, Bolt On & Go installation.



The throttle cable firewall bracket uses the factory clutch cable opening in the firewall. There is already one hole that is used to secure the factory clutch cable, so you must make another hole for the throttle cable bulkhead. This picture was taken facing the firewall.



(813) 928-1449

www.FFPCustoms.com



With all the different throttle cable lengths and applications, we do not include one with our pedal assembly. However, this Lokar cable is an example of what we recommend. The Lokar TC-1000U36 is a 36" cable, which may work for some of you, while others may need a longer or shorter throttle cable. The throttle cable attaches to the top of the throttle pedal using the attached clevis, goes through the firewall, and then attaches to your car's throttle linkage.

If you have made it this far, you have now installed the main structure, brake pedal assembly and throttle pedal assembly. If you are installing a clutch, brake, and throttle pedal assembly, you still have a little work to do. However, if you are installing a brake and throttle-only pedal assembly, you are ready for a blast down the track.

Remember, if you have any questions, feel free to contact us via phone or social media. We would rather you contact us for clarification instead of being frustrated with the installation.

Proudly Made in the USA.

FFP Customs

(813) 928-1449

www.FFPCustoms.com